



Rev. A - 3/06/2007

Notice: Do not expose timer to heat or moisture

LaSpaziale Vivaldi II Clock Module



General Notes

- a) With the selection of English as the language, the time of the day is shown in standard HH:MM am/pm format on the first line. The date is show on the 2nd line in standard MM-DD-YY format.
- b) The clock module automatically adjusts for leap years.
- c) The clock module automatically adjusts for Daylight Savings Time, if selected. However, this feature has not been changed for the new US DST dates. Consequently, it is best to leave this feature off.
- d) The times and dates on your timer may be different than shown in this manual since they will depend on how your unit was previously set when entering configuration mode.

1. OPERATING INSTRUCTIONS


With power on, the first line displays the current time (01:00pm). The second line alternates between the current date and the next off "OF" or on "ON " time (OF08:30pm), if an on/off operation is pending before midnight of the current day.



Page 2 of 8

1.1 Timer programming

Pressing the button for about 3 sec. enters the programming mode with the word "Timer Selectio" displayed. Use the buttons to select the desired mode then confirm with the button set.



1.2 "Language Selectio" Mode

Confirm Language mode with the button and on the display the language previously selected is flashing.

On the top line: Selectio

On the bottom line: English (flashing)

Use the buttons 1 to select the language among: Italian – English – French – German

Spanish and confirm with

1.3 "Clock Selectio" Mode

With the button confirm Clock mode. The following message is shown on the display:

On the top line: Day

On the bottom line: Monday (flashing)

With the buttons select the day of the week and confirm with

The following message is shown on the display:

On the top line: Month

On the bottom line: <u>January</u> (flashing)

With the buttons **1 ...** select the month and confirm with ...

On the top line: Day On the bottom line: 30 (flashing) With the buttons select the date of the week and confirm with . The following message is shown on the display: On the top line: Year On the bottom line: 2007 (flashing) With the buttons **1 1** select the year and confirm with **3**. The following message is shown on the display: On the top line: Time On the bottom line: 12:00am (with the hour digit flashing) With the buttons select the hour including am/pm and confirm with . The digits of the minutes start flashing. With the buttons 10 uset the minutes then press The displayed message changes to: On the top line: Summerti (Daylight Savings Time) On the bottom line: NO – YES (with flashing Yes) With the buttons select: **YES** = Change to Daylight Savings Time on the last Sunday of March at 02:00am and change back to Standard time on the last Sunday of October at 03.00am. **NO** = No change to summer time (DST) occurs. then press . The display then shows Clock Selectio. Press to cycle back to the beginning of Clock Selectio mode or **1** to exit programming mode.

1.4 "Timer Slectio" Mode

With the button confirm Timer mode. The following message is shown on the display:

On the top line: Timer

On the bottom line: OFF – ON (with flashing ON)

The following message is shown on the display:

With the buttons
 select:

OFF If you want to disable use of the timer function to turn the S1 on and off.

ON If you want to enable the timer to turn the S1 on and off at the programmed times, then confirm it with the button

The display then changes to:

On the top line: Monday (flashing)

On the bottom line: -----

With the buttons •• , select the day and then confirm with button •• . The selected day becomes fixed and abbreviated followed by the message:

On the first line: Mon 1° ON

On the second line: 12:00am (with the first two flashing digits)
With the buttons 1 select the hour and confirm with ...

This makes the digits corresponding to the minutes flash. With the buttons 1 select the minutes and confirm with . The message Mon 1° ON becomes Mon1° OFF. On the second line: 12:00am (with the first two flashing digits)

Use the same procedure as above to select the first hour for OFF. By confirming it, the message Mon 1° OFF becomes Mon 2° ON and, once it is confirmed, it becomes Mon 2° OFF. The same procedure is valid for the 3rd time setting. Once the Mon 3° hour of OFF is programmed, the display changes to:

Top line: Tuesday (blinking)

Bottom line: Copy

If you want to copy the setting made the previous day, you have to press the button and hold for three seconds. If you wish to copy a single day's schedule such as Mondays all the way through Friday, for example, press again and hold the button for 3 seconds as you cycle through each day. If you want to just move to the next day to set up a schedule different than that just programmed, momentarily press the button. You can then program the next and and subsequent days for up to three different On / Off times just as the Monday example described above. After each day you can press for three seconds to copy to the next day or momentarily press the button to move to the next day.

After selecting the last day of the week, you go back to the "**Timer Selectio**" display. Presses to cycle back to the beginning of Clock Selectio mode or **1** to exit programming mode.

Special Case Settings:

- If the ON and OFF time are both set to the same time, the machine remains off.
- ➤ If the ON time of the next time setting is the same as the OFF time of the previous setting, the machine stays on.
- If there is one minute of difference (OFF 11:59pm ON 12:00am) between the OFF time of one specific day and the ON time of the following one, the machine stays on.

2. EXAMPLES OF TIMER PROGRAMMING

1st example:

In case you want to switch on the machine at 07:00am and switch it off at 09:00pm during the whole week, proceed as follows:

Press for 3 sec. the button , confirm **Timer Selectio** mode with the button . Select "TIMER ON" with the buttons , then confirm with .

The first line of the display shows Monday, confirm with the button .

Set with the buttons 1 1 7:00am as time and confirm with the button . Set the minutes as 00 and confirm with the button (for programming instructions see paragraph 1.4).

The display shows on the first line MON 1° OFF, set with the buttons 1 09:00 pm as time and confirm with the buttons 1, then set the minutes 00 and confirm with the buttons

Set the following times all to 9:00PM and confirming each with the button (Mon 2° ON, Mon 2° OFF, Mon 3° ON, Mon 3° OFF) until the display shows Tuesday on the first line and COPY on the second line.

Press button for 3 sec. so as to copy the time setting of the previous day. The display shows Wednesday on the first line and COPY on the second line.

Press the button for about 3 sec. so as to copy the time setting of the previous day.

Repeat the same operation for all days of the week.

After selecting the last day of the week, the display returns to "Timer Selectio" mode.

2nd example:

In case you want to set a day of the week for which the machine does not turn on (for example Sunday) proceed as follows:

Set the desired on and off time of all days of the week (for programming instructions see paragraph 1.4). When the Timer displays Sunday, confirm with the button .

With set the ON and OFF time at 12:00am in the first time setting. Confirm the same time for all the following time settings with the button .

3rd Example:

In case you want to switch on the machine from 07:00am Monday through 11:00pm on Saturday proceed as follows:

Press for 3 sec. the button . Select "TIMER ON" with the buttons 1 .

The first display line shows Monday. Confirm with the button 🚓 .

Set with the buttons 1 7:00am as Mon 1 ON and confirm with the button (for programming instructions see paragraph 1.4).

The display shows on the first line MON 1° OFF. Set with the buttons 1 11:59pm as Mon 1° OFF and confirm with the button .

Set the following times all to 12:00am and then confirm each setting with button (Mon 2° ON, Mon 2° OFF, Mon 3° ON, Mon 3° OFF) until the display shows TUESDAY on the top line and COPY on the bottom line.

Press the button and set as Tues 1° ON time 12:00am. Confirm with the button The display shows on the first line Tues 1° OFF. Set with the buttons 1 11:59 pm as Mon 1° OFF and confirm with the button.

Set the following times all to 12:00am and confirm each setting with the button (Tues 2° ON, Tues 2° OFF, Tues 3° ON, Tues 3°OFF) until the display shows WEDNESDAY on the first line and COPY on the second line.

Press the button for 3 sec. so as to copy the time settings of the previous days. Repeat the same operation for all the other days until the display shows Saturday. Confirm with the button Set the time 12:00am (Sat 1° On) and confirm with the button The display shows Saturday time Sat 1° OFF on the first line. Set the time to 11:00pm (Sat 1° OFF) and confirm with the button Set.

Set the following times to 11:00PM and confirm with the button (Sat 2° ON, Sat 2° OFF, Sat 3° ON, Sat 3°OFF) until the display shows SUNDAY on the first line and Copy on the second line.

With the buttons **1 1** set ON and OFF at 12:00am in the first time setting. Confirm with the button **4** the same time for all the other time settings.

After selecting the last day of the week the display goes back to the "Timer Selectio" mode.

3. Battery Backup

When power is off to the Vivaldi II, there is no power provided to the timer. In this mode the timer display is off but the time and program are maintained in battery backed memory. A 3V CR2032 Lithium button battery is used for this purpose. This battery should last for several years.

4. Other Operational Notes

- There is no Back button. If you make an error or miss a critical step, you need to just stop and wait for the programming mode to time out. The timer will then revert to time mode and you can start over with programming.
- ➤ If you can't figure out how to get the timer to do what you want from this manual, please log into the S1 forum and ask for assistance: http://s1forum.rimpo.org.
- This manual assumes that you have purchased your S1 Vivaldi II with Timer option installed. If you purchased your timer later, please request installation assistance from Chris Coffee Service: http://www.chriscoffee.com/contact.